

# ISM00D

## II Plus

### User Guide











Please read and understand this manual  
carefully before using this product.



## 1. OVERVIEW:

**ISMOD II Plus** is a heat device that does not burn which comes with a build-in large capacity lithium battery, two smoking holders and a large charging base that makes it portable, convenient and durable.


## 2. PACKAGE CONTENT

Protective top cover 	 Charger	Protective top cover 	 User Guide
ISMOD holder 		ISMOD holder 	
 Cleaning sticks	 Charging cable		 Cleaning plate
			 Cleaning brush

## 3. PARAMETERS


Model	ISMOD II Plus
Power Requirement	Battery Capacity(2600mAh,3.7v) Maximum Discharger Current: 2A
Charging Time	Power Bank charging time: 3 hours;
Charging Method	ISMOD holder charging time: 6 min
Working Temperature	5-40°C
Product Size	101mm*55mm*21mm
Product Weight	115g

## 4. OPERATING INSTRUCTIONS




## 5. INSTRUCTION MANUAL:


### 5.1 Preparation




1. Remove ISMOD holder from the Charging unit.



3. Press the button and hold for 1.5 seconds, until ISMOD holder vibrates. ISMOD holder starts to preheat the cartridge of non-combustible tobacco.




2. Insert cartridge of non-combustible tobacco into the ISMOD holder.




4. Wait for 15 seconds until the device vibrates to indicate that the pre-heating process of non-combustible tobacco has been finished.



5. After the blue light turns solid on you can start using it. When the smoking reaches 12 puffs, ISMOD holder generates a prompt vibration and the blue light flashes. When smoking reaches 14 puffs or when the heating time finishes, ISMOD holder stops working and a final vibration is generated.



6. Remove the cartridge of non-combustible tobacco along with the top cover after finish.



7. Remove the cartridge of non-combustible tobacco from the top cover.



### Note:

**When you remove the protective top cover after use, pay attention to the warning sign on the internal insulation of the ISMOD holder. When installing the protective top cover again, pay attention on the position to prevent damage to the ISMOD holder.**

#### Termination of use.

1. If you need to stop using it before the smoking operation ends, press and hold the control switch for 1.5 seconds, the ISMOD holder will stop working and enter a shutdown state, and the indicator light will go out and a vibration prompt will be generated.
2. Under normal working conditions of usage, after completion of use, the ISMOD holder generates a vibration alert, and the ISMOD holder indicator flashes and then enters a shutdown state.
3. After you have finished using it, put the ISMOD holder back into the Charging unit to charge, so that it can be used again next time.




#### **NOTE:**

**UNDER NORMAL WORKING STATE OF USAGE, IF THE NUMBER OF AEROSOLS IS SIGNIFICANTLY REDUCED, OR THE AEROSOL TASTE IS WEAKENED, IT MEANS THAT THE CARTRIDGE OF NON-COMBUSTIBLE TOBACCO HAS BEEN USED AND IT NEEDS TO BE REPLACED.**

## 6. CHARGING INSTRUCTIONS

#### Charging unit operation instructions

1. It is recommended to charge the Charging unit for the first time to ensure the normal use of the product.



2. When you are ready to charge the Charging unit, align the charging cable with the USB charging port and the other end for the power connection.

3. When charging, the charging indicator of the host will flash in sequence until the indicator is solid, indicating that charging is complete.

#### ISMOD holder charging instruction

1. Before you prepare to charge the ISMOD holder you will need to ensure that the Charging unit is turned on and that there is enough power available.

2. After you have finished consuming each cigarette, you need to charge the ISMOD holder to use it again.


3. When charging, you need to align the charging interface of the ISMOD holder with the Charging unit. The magnetic function of the product will automatically turn on and charge.

4. The corresponding cigarette charging indicator will flash when charging, red flash indicates that charging is in progress, blue flash indicates charging is complete.

5. After the ISMOD holder is fully charged, the indicator will automatically go out.

## 7. CLEANING AND MAINTENANCE


The product itself comes with a cleaning kit for the cleaning and maintenance of the ISMOD holder and the protective top cover.




1. When cleaning the ISMOD holder, pull out the protective top cover of the ISMOD holder, insert the cleaning brush according to the following picture, turn it several times, then remove the residue on the cleaning brush, and afterwards, use the cleaning sticks and finish with the cleaning plate.
2. To prevent clogging of the holes in the protective top cover, use the included cleaning sticks and cleaning plate to clean it.

### How to use the cleaning stick?

1. Remove one stick from the string of sticks



2. Tear open the packaging and remove the cleaning stick.



## 8. Notice:

1. The product is not available for minors and people who are weak both physically and mentally or unaware of the safe usage of it, please take care of it. (Accident risk)
2. Do not use the device if the top cap has been removed to avoid scalding from the heating accessories. (Burn Risk)
3. Do not put the device to any other use except for what is indicated in the user guide. (Accident risk)
4. Do not immerse the device or any accessories into the water. (Risk of failure, this product is not waterproof)
5. Do not use any charging device which isn't up to the standard. (Accident risk)
6. Stop charging or using the device if a bad smell, or smoke, appears and contact your service provider immediately. (Accident risk)
7. If there is any battery leakage, keep the leaked liquid away from the skin and eyes. Please wash it immediately with water and seek medical treatment at once. (Accident risk)



## 9. COMMON PROBLEMS AND CORRESPONDING SOLUTIONS

The charging unit could not turn on	Check if there is enough power in the charging unit	Charge the charging base until there is enough power within it
	Check the charger if it hasn't been used for a long time	The battery is low, charge the charging base at once
	Check if there is something wrong with the button	Send the device to the local service center
	Check if there is something wrong with the indicator	Send the device to the local service center
The charging unit is not charging	The charging unit can't get charged	Send the device to the local service center
ISMOD holder is not charging	Check if the ISMOD holder is charging	Never charge the charging unit and the ISMOD holder simultaneously
	Check if the charging port is broken	Send the device to the local service center
The indicator blinks abnormally	Check if the red-light blinks when the button is pressed and go out when released	The battery is low, charge the device at once
	Prevent the device from getting overheated	Wait for 3-5 mins until the temperature of the device is normal
	Check if there is something wrong with the heating blade	Send the device to the local service center

## 10. DISCLAIMERS

Please follow the instructions of safety precautions, which are essential.

1. The ISMOD II Plus is battery powered. It needs to get recharged when the battery is low. Do not put the ISMOD II Plus near high-temperature environment or heater to avoid battery damage.
2. Read all the instructions carefully before you use the ISMOD II Plus. Keep the User Guide for future reference. When using the ISMOD II Plus, follow the manufacturer's instructions to avoid the possible injuries. The warnings and safety instructions in this User Guide cannot involve all the possibilities and situations that may occur. Be cautious when you use or maintain any personal electronic product.
3. Use the exclusive cartridge of non-combustible tobacco intended for this device only.
4. SMOD II Plus contains lithium batteries, for their disposal, please follow the requirement of local government.

### **LITHIUM BATTERY**

1. If the product is kept at a high temperature for a long time, the degradation of the lithium battery occurs.
2. The battery will discharge when it is stored for a long time without operation. Please recharge the device before using.
3. When you do not use the device for a long time, avoid storing the device in fully-charged status or under high temperature/humidity condition in order to avoid accelerated deterioration of the battery.